

HV 2/2

List of spares

When placing orders for spares, never forget to mention the required number of pieces, the type or number; for illustration no. 1 also the voltage,

periodicity an the arrangement of the fastening holes HV 2, HV 2 BC or HV 2 B2.




Fig. No.	Order No.	Pieces			
		HV2/2	HV2/2-2	HV2/2-4	HV2/2-6
1	6 0 8 0 1 housing complete HV 2/2 or	1	1	1	1
1	6 0 6 5 1 housing complete HV 2/2 BC or	-	1	1	1
1	6 0 8 3 1 housing complete HV 2/2 B2	-	-	1	1
2	protecting cover	2	2	2	2
3	screw for protecting cover	4	4	4	4
4	armature	1	1	1	1
5	0 0 4 0 1	1	1	1	1
6	2 1 1 0 1	1	1	1	1
7	2 1 3 0 1	4	4	4	4
8	2 2 5 5 1	2	2	2	2
9	2 4 3 0 1	2	2	2	2
10	2 7 0 0 1	2	2	2	2
11	2 9 5 0 1	1	1	1	1
12	2 9 6 0 1	1	1	1	1
13	2 9 7 0 1	1	1	1	1
14	7 5 3 1 1	8	12	16	26
15	7 5 8 0 1	1	1	1	1
16	7 5 9 1 1	2	2	2	2
17	7 6 4 0 1	2	2	2	2

